



**Make a difference**

**DIGITAL MULTIFUNCTION METER**

**User Manual**

**MT-DP96HMF**



Version 1.0

Thanks for choosing our product – MT-DP96HMF, Please read this manual carefully and pay attention to below caution matters.

## CAUTION

- ✓ This product should be installed and maintained by professional person
- ✓ Before operating this product inside or outside, please cut off the input signal and power supply;
- ✓ Please make sure all parts of the product don't have voltage by suitable voltage detection device
- ✓ The power supply should be within the rated range

The below situation will result in device damage and abnormal working

- ✗ Auxilliary power source voltage over range
- ✗ Distribute system frequence over range
- ✗ Current, voltage input polarity incorrect
- ✗ Disconnect the communication plug under charged situation
- ✗ No according requirement to connect terminal



Please don't touch the terminals when the meter is in operation!

## CONTENTS

1. Function introduction.....	3
2. Technical parameter.....	3-4
3. Installation and correction.....	4-5
4. Display and buttons.....	6-13
5. Programme operation.....	13-16

## 1. Function introduce


Measure function	Remark
Realtime measure	Three phase voltage (L-L, L-N)
	Three phase current and neutral current
	System Frequence
	P, Q, S, PF (per phase & total)
Electric energy	KWh import
	KVARh import
	KWh export, KVARh export
Harmonics	THDU per phase
	THDI per phase
	HDI per phase from 2 <sup>nd</sup> to 31 <sup>st</sup> order
	HDU per phase from 2 <sup>nd</sup> to 31 <sup>st</sup> order
Communication	RS485 Port MODBUS-RTU
Maximum Demand/	U,I,P,Q
Analog output/	0-20mA/ 4-20mA/ 0-5V/ 0-10V
Digital input/	Dry contact type/
Relay output/	AC250V 5A Remote/ Alarm
Display type/	LCD

## 2. Technical parameter


Parameter		
Signal Input/	Connection system	3P3W/ 3P4W
	Measurement range	519V L-L
	Over load	Continous: 1.2 Vn; Instantaneous: 2Vn
	Power consumption	< 1VA
	Measurement range	5A/ 1A
	Over load	Continous: 1.2In; Instantaneous: 2In
Frequency	Power consumption	< 1VA
		45 - 65Hz
Auxiliary power suply	AC85-265V DC100-300V	
Communication	RS485 communication port, physical layer isolation. According international standard MODBUS-RTU agreement. Communication speed 1200-38400 (Default 9600) Test type N81, E81, 081 (Default N81)	
Analog output	0-20mA/ 4-20mA/ 0-5V/ 0-10V	
Relay output	Programme remote/ Alarm switching ouput Capacity 5A at 250VAC/ 30VDC	


Digital input	Remote switch input signal, dry contact input. Program relate alarm output
Measure class	Current, Voltage, Active power, Energy: 0.5S; Reactive power: 1S; Frequency: $\pm 0.1\text{Hz}$
IP protection	IP53 for indoor type and PI65 for outdoor type
Environment	Working temperature: $-10\div 55^\circ\text{C}$ Store temperature: $-20\div 75^\circ\text{C}$ Relative Humidity:<80%RH
Safe	Isolation: Signal, auxiliary power supply, output terminal crust resistance $>5\Omega$ and withstand voltage pulse $>\text{AC}2\text{kV}$

### 3. Installation and correction




LxH (mm)	AxB (mm)	SxY (mm)	SxY (mm) IP65	N (mm)	M (mm)
96x96	90.5x90.5	91x91	91.5x91.5	94	88






Active Pulse		Reactive Pulse		RS485		Aux. Power Suply			
Ep-	Ep+	Ep-	Ep+	B	A	N(V-)	L(V+)		
48	47	50	49		59	58		2	1

Relay Output				Digital input				Analog output									
DO1	DO2	DO3	DO4	COM	DI1	DI2	DI3	DI4	A0-	A01+	A02+	A03+	A04+				
15	16	17	18	19	20	21	22	70	71	72	73	74	30	31	32	33	34



#### 4. Display & Buttons



- Four lines digital display measure information: Three phase voltage, three phase current, active power, reactive power, power factor, frequency, switch input, output, other switch input, two way active power, two way reactive power, analog input, demand
- K is light mean practice value is display value is 1.000 times. M is light mean practice value is display value is 1.000.000 times
- Measure item unit or characterise: three phase voltage V, three phase current A, active power W, reactive power VAR...
- Buttons use in change or programme set:



is change page button or value increase or decrease button



is enter programme status



is select confirm button

If there is no relative symbol display or the set data not working, It means the product without the relative function

Board	Content	Explain
DISP=1 -Three phase voltage -Forward active energy Kwh	 <p>The display shows three-phase voltages: a = 5774 V, b = 5774 V, c = 5774 V. Below the voltages, the forward active energy is displayed as 00290805 kWh.</p>	Separate display voltage $U_a$ , $U_b$ , $U_c$ (in the 3P4W)  In left fig. $U_a=5774V$ $U_b=5774V$ $U_c=5774V$  Forward active energy = 2908.05KWh

DISP=2 -Three phase voltage -Reverse active energy Kwh	 <p>The display shows three-phase voltages: ab = 10.00 KV, bc = 10.00 KV, ca = 10.00 KV. Below the voltages, the reverse active energy is displayed as -00100002 kWh.</p>	Separate display voltage $U_{ab}$ , $U_{bc}$ , $U_{ca}$ (in the 3P4W)  In left fig. $U_{ab}=10KV$ $U_{bc}=10KV$ $U_{ac}=10KV$  Reverse active energy = 1000.02Kwh
--	--	--

DISP=3 -Three phase current -Forward reactive energy Kvarh	 <p>The display shows three-phase currents: a = 5.000 A, b = 5.000 A, c = 5.000 A. Below the currents, the forward reactive energy is displayed as 00005000 kvarh.</p>	Separate display current $I_a$ , $I_b$ , $I_c$ (in the 3P4W)  In left fig. $I_a=5A$ $I_b=5A$ $I_c=5A$  Forward reactive energy = 50Kvarh
--	--	---

DISP=4

- Total active power
- Total reactive power
- Total apparent power



Total active power  
= 86.6KW

Total reactive power  
= 0000Kvar

Total apparent power  
=86.6KVA

Reverse reactive energy  
=100.08Kvarh

DISP=5

- Active power phase A
- Reactive power phase A
- Apparent power phase A



Active power of phase A  
= 28.87KW

Reactive power of phase A  
= 0000Kvar

Apparent power of phase A  
=28.87KVA

Forward active energy  
=2908.05KWh

DISP=6

- Active power phase B
- Reactive power phase B
- Apparent power phase B



Active power of phase B  
= 28.87KW

Reactive power of phase B  
= 0000Kvar

Apparent power of phase B  
=28.87KVA

Reverse active energy  
=1000.02KWh

DISP=7

- Active power  
phase C

-Reactive power  
phase C

-Apparent power  
phase C



Active power of phase C  
= 28.87KW

Reactive power of phase C  
= 0000Kvar

Apparent power of phaseCB  
=28.87KVA

Forward reactive energy  
=50.00KVARh

DISP=8

- Average current

-Zero sequence current



Average current = 5A

Zero sequence current = 0.06A

Reverse reactive energy  
=50.00KVARh

DISP=9

- Three phase total power factor

-Frequency

-Voltage unbalance




Three phase total power factor  
=1.000

Frequence = 50Hz

Voltage unbalancedness = 9V

Forward active energy  
=2908.05KWh

DISP=10  
Split phase power factor




Power factor of phase A  
=0.999 (inductive load)

Power factor of phase B  
=0.999 (inductive load)

Power factor of phase C  
=0.999 (inductive load)


Reverse active energy  
=1000.02KWh

DISP=11  
Total voltage harmonic









In the left fig:  
a.b.c phase total voltage harmonic  
=10%


DISP=12  
2nd voltage harmonic



In the left fig:  
2nd voltage harmonic of a.b.c phase  
=10%

<p>Omitted to</p> <p><b>DISP = 41</b></p> <p>31st voltage harmonic</p>	 <p>The digital meter display shows three rows of data for phases a, b, and c. Each row consists of a small graphic icon followed by a digital readout and a unit indicator. The first row is labeled 'a' and has a 'THD' icon, followed by '0 100 % v'. The second row is labeled 'b' and has a 'THD' icon, followed by '0 100 % v'. The third row is labeled 'c' and has a 'THD' icon, followed by '0 100 % v'. Below these rows, the number '-31' is displayed. At the bottom of the screen are four function keys: 'SET', '▲', '▼', and 'ENT'.</p>	<p>Omitted to</p> <p>In the left fig: 31st voltage harmonic of a, b, c phase =10%</p>
<p><b>DISP = 42</b></p> <p>Total current harmonic</p>	 <p>The digital meter display shows three rows of data for phases a, b, and c. Each row consists of a small graphic icon followed by a digital readout and a unit indicator. The first row is labeled 'a' and has a 'THD' icon, followed by '0 100 % A'. The second row is labeled 'b' and has a 'THD' icon, followed by '0 100 % A'. The third row is labeled 'c' and has a 'THD' icon, followed by '0 100 % A'. Below these rows, the number '-01' is displayed. At the bottom of the screen are four function keys: 'SET', '▲', '▼', and 'ENT'.</p>	<p>In the left fig: a.b.c phase total current harmonic =10%</p>
<p><b>DISP = 43</b></p> <p>2nd current harmonic</p>	 <p>The digital meter display shows three rows of data for phases a, b, and c. Each row consists of a small graphic icon followed by a digital readout and a unit indicator. The first row is labeled 'a' and has a 'THD' icon, followed by '0 100 % A'. The second row is labeled 'b' and has a 'THD' icon, followed by '0 100 % A'. The third row is labeled 'c' and has a 'THD' icon, followed by '0 100 % A'. Below these rows, the number '-02' is displayed. At the bottom of the screen are four function keys: 'SET', '▲', '▼', and 'ENT'.</p>	<p>In the left fig: 2nd current harmonic of a, b, c phase =10%</p>





## 5. Programme operation

In programme status, digital interface adopt layers structure menu type, meter supply three lines number display (see fig. 5)



Fig.5

No.1 line is first layer menu information;

No.2 line is second layer menu information;

No.3 line is third layer menu information;

Exp: The fig.5 shown: No.1 layer: INPT = Signal input; No.2 layer: CT = current transformer; No.3 layer: current value is 5, It means ratio of CT is 25/5A.

The digital display interface menu has the following organizational structure, the user can choose the appropriate setting parameters according to the actual situation.

No.1 Layer	No.2 Layer	No.3 Layer	Description
System SET	Display DISP	0000-0017	0000 mean automatic cycling display. Each board connect see table 6
	DISL	0001-0003 or 0000-0120	0000-0120 is keeping time of LCD back light. 0000 means the backlight keeping ON
	Data clear CLR. E	1111	1111 means the data clear other value is invalid

Signal Input  INPT	Wiring type Net	0000 or other value	0000 mean 3P4W system. Other value is mean 3P3W system
	Voltage trans. ratio PT	1~9999	PT value= PT primary value/ secondary value
	Current trans. ratio PT	1~9999	CT value= CT primary value/ secondary value


Communication Set CON <i>i</i> ( <i>i</i> is 1~ 2)	Address SN	1~247	Meter address range 1 to 247
	Communication speed BAUD	0001~0004	0001 is 1200; 0002 is 2400; 0003 is 4800; 0004 is 9600; 00005 is 9200; 00006 is 38400
	Data format DATA	0001~0003	0000 is E,8, 1; 0001 is 0,8,1; 0002 is N,8,1


Digital output Set  DO- <i>i</i> ( <i>i</i> is 1~4)	Choose alarm item or close alarm	Set alarm item's specific threshold value	Choose alarm item, and set relative threshold value (when alarm item is digital value, no need set threshold value), once meet alarm condition, switch output working
--	--	---	--

Analog output Set  AO- i ( i is 1~4)	Choose transmitter item or close analog output (refer to 8.2 analog output)	Set the full scale value of analog item	Choose transmitter item's and relative electrical parameter (0-20mA, 4-20mA, 4-12-20mA) For example, set "A0-1" TYPE"0135" UAL"5000", which means A phase current 0-5A corresponds to the transmitter output signal of first loop 4-20mA
---	---	---	---

Note: The above menu is applied to the product with complete functions. If you find there is no such menu in the product or the menu is not working, It means the product not supporting the function.

Hold SET button in  
3 seconds





(Analog capacity output: other three ways is similar)